

SUPPLY ONLY

Sliding Robe Doors

Robes & Screens

Hills



HILLS ROBES & SCREENS

HOW TO ORDER

1

Measure your robe space using our online how-to measuring guide.

2

Choose your frame and panel colours from the options available on our website.

3

Complete our online **Supply Only Quick Quote** form, and one of our team members will be in contact with a price!

SUPPLY ONLY SLIDING ROBE DOORS

If you're renovating and looking to save money, or a tradesperson looking for a reliable, local manufacturer of sliding robe doors, Hills Robes & Screens offer an affordable Supply Only Sliding Robe Door solution to meet your needs.

Custom-made in our Sunshine Coast factory, our supply only wardrobe doors offer a cost-effective option for your wardrobe upgrade. Hills provide a fast turn-around time and friendly, professional service. Once your doors have been made, you can collect them direct from our Caloundra factory and install them yourself.

Our supply only sliding robe doors are easy to install, and come in a variety of frame colours and panel finishes to suit all styles and tastes.

Or phone **07 5491 7567** for an on-the-spot quote.

SUPPLY ONLY


Sliding Robe Doors

Robes & Screens

Hills



BASIC
TOOLS
NEEDED



DRILL



TAPE MEASURE



DROP SAW



SPIRIT LEVEL



FREQUENTLY ASKED QUESTIONS

Do you offer a delivery service?

Unfortunately, no. Supply Only Robe Doors must be collected from our showroom at Caloundra West. A suitable vehicle to accommodate the doors is essential, i.e. taking into account the size of the doors and how they will fit in your tray or trailer.

Will my robe doors come packed and wrapped?

Hills Robes & Screens do not have the facilities to pack the robe doors ready for transport (plus this would add significantly to the cost). It is advised that you bring suitable items, e.g. blankets, doonas, large sheets or thick cardboard, etc. in order to ensure your robe doors are protected from scratches, dents, etc. while in transit.

Why is my wardrobe track longer than the supplied measurements?

We provide the tracks approx. 100mm longer than required so that you can trim them to the exact measurement of your door opening. You will ideally need a drop saw to cut the track cleanly.

What is the best way to secure the tracks?

When installing the robe doors, the bottom track is to be fitted firmly between the wall jambs. There is no need to screw the bottom track down as the firm fit and weight of the doors once in place, should ensure the track does not move. The top track will need to be screwed to secure it into place.

What happens if my floor is not level?

It may be necessary to adjust the wheels on the bottom of the doors to ensure the doors sit flush against the jamb when closed and don't roll away. If your floors are out of level by more than 6mm, speak to our customer service team about whether this option is right for you.

07 5491 7567

13 INDUSTRIAL AVENUE, CALOUNDRA, QLD, 4551

INFO@HILLSWARDROBES.COM.AU